

BJ Jumper bar

Use the BJ jumper bar to connect consecutive and nonconsecutive terminal blocks with the same spacing. Two types of jumper bars are available : an assembled unit and a nonassembled unit. Both jumper bars include a metal tube which makes contact with the terminal block's internal connector bar.

To mount the BJ jumper bar accessory onto terminal blocks still having top center partitions, the user must cut out all partitions between the blocks.

When the BJ jumper bar is used with each of two series of connected blocks, the top center opening at the junction of the two series must be closed by a circuit separator or a separator end section SCM, SCF or SCD to permit different voltage potentials on each series jumper bar accessory.



BJM Assembled jumper bar

Two versions of this accessory are available.

Fractionable model, composed of captive screws on a jumper bar system. This accessory can be used for connecting consecutive blocks only.

Simplified model, composed of a bar prepunched to the spacing of the blocks, and of captive screws and spacers. This accessory can be used for connecting blocks, which are consecutive or not : in this case remove the screw and spacer which are not required.

without IP20 protection (standard)



Current capacity, Amps

BJM5 for MA 2,5/5 blocks			
24 A	2 poles		0176 273.01
24 A	3 poles		0176 274.02
24 A	4 poles		0176 275.03
24 A	5 poles		0176 276.04
24 A	10 poles		0176 277.05
BJM6 for M 4/6 blocks			
32 A	2 poles		0168 516.25
32 A	3 poles		0168 517.26
32 A	4 poles		0168 518.07
32 A	5 poles		0168 519.00
32 A	10 poles		0168 973.07
BJM8 for M 6/8 blocks			
41 A	2 poles		0168 520.05
41 A	3 poles		0168 521.22
41 A	4 poles		0168 522.23
41 A	5 poles		0168 523.24
41 A	10 poles		0168 974.00

Max. recommended torque : **0.6 Nm**

with IP20 protection (touchproof)



Current capacity, Amps

BJMI5 for MA 2,5/5 blocks			
24 A	2 poles		0176 278.16
24 A	3 poles		0176 279.17
24 A	4 poles		0176 280.05
24 A	5 poles		0176 281.22
24 A	10 poles		0176 282.23
BJMI6 for M 4/6 blocks			
32 A	2 poles		0176 663.00
32 A	3 poles		0176 664.01
32 A	4 poles		0176 665.02
32 A	5 poles		0176 666.03
32 A	10 poles		0176 667.04
BJMI8 for M 6/8 blocks			
41 A	2 poles		0176 669.16
41 A	3 poles		0176 670.13
41 A	4 poles		0176 671.00
41 A	5 poles		0176 672.01
41 A	10 poles		0176 673.02

Max. recommended torque : **0.6 Nm**

without IP20 protection (standard)



Current capacity, Amps

BJM5D for MA 2,5/5.D blocks			
24 A	2 poles		0176 226.22
24 A	3 poles		0176 227.23
24 A	4 poles		0176 228.04
24 A	5 poles		0176 229.05
24 A	10 poles		0176 230.02
BJM6D for M 4/6.D blocks			
32 A	2 poles		0173 515.11
32 A	3 poles		0173 516.12
32 A	4 poles		0173 517.13
32 A	5 poles		0173 519.25
32 A	10 poles		0173 520.22
BJM62 for D 4/6.LNTP, DR 4/6 blocks			
32 A	2 poles		0173 217.26
32 A	3 poles		0173 218.07
32 A	4 poles		0173 219.00
32 A	5 poles		0173 221.22
32 A	6 poles		0174 112.16
32 A	7 poles		0174 113.17
32 A	8 poles		0174 114.10
32 A	9 poles		0174 115.11
32 A	10 poles		0173 226.27
BJM65 for M 4/6,5.3G blocks			
32 A	2 poles		0174 764.03
32 A	3 poles		0174 765.04
32 A	4 poles		0174 766.05
32 A	5 poles		0174 767.06
32 A	10 poles		0174 768.17
32 A	25 poles		0174 769.10

BJM10 for M 10/10 blocks			
57 A	2 poles		0173 611.21
57 A	3 poles		0173 612.22
57 A	4 poles		0173 613.23
57 A	5 poles		0173 614.24
57 A	10 poles		0173 615.25

BJM12 for M 16/12 blocks			
76 A	2 poles		0179 618.16
76 A	3 poles		0179 619.17
76 A	4 poles		0179 620.14
76 A	5 poles		0179 621.01
76 A	10 poles		0179 622.02

BJM16 for M 35/16 blocks			
110 A	2 poles		0179 613.01
110 A	3 poles		0179 614.02
110 A	4 poles		0179 615.03
110 A	5 poles		0179 616.04
110 A	10 poles		0179 617.05

BJM4 for DR 1,5/4 blocks			
17,5 A	2 poles		0205 735.06
17,5 A	3 poles		0205 736.07
17,5 A	5 poles		0205 737.00
17,5 A	10 poles		0205 738.11

Max. recommended torque : **0.6 Nm**
except for **BJM16 (1.2 Nm)**

with IP20 protection (touchproof)



Current capacity, Amps

BJMI5D for MA 2,5/5.D blocks			
24 A	2 poles		0176 736.21
24 A	3 poles		0176 737.22
24 A	4 poles		0176 738.03
24 A	5 poles		0176 739.04
24 A	10 poles		0176 740.11
BJMI6D for M 4/6.D blocks			
32 A	2 poles		0179 668.20
32 A	3 poles		0179 669.21
32 A	4 poles		0179 670.26
32 A	5 poles		0179 671.13
32 A	10 poles		0179 672.14

BJMI10 for M 10/10 blocks			
57 A	2 poles		0176 675.04
57 A	3 poles		0176 676.05
57 A	4 poles		0176 677.06
57 A	5 poles		0176 678.17
57 A	10 poles		0176 679.10

BJMI12 for M 16/12 blocks			
76 A	2 poles		0179 626.06
76 A	3 poles		0179 628.10
76 A	4 poles		0179 629.11
76 A	5 poles		0179 630.16
76 A	10 poles		0179 631.03

Max. recommended torque : **0.6 Nm**

BJD Assembled jumper bar

Only one version of this accessory is available

Simplified model, composed of a bar prepunched to the spacing of the blocks, and of captive screws and spacers. This accessory can be used for connecting blocks, which are consecutive or not : in this case remove the screw and spacer which are not required.

without IP20 protection



Current capacity, Amps

BJD6 for D 2,5/6.D blocks, triple deck			
24 A	2 poles		0178 024.25
24 A	3 poles		0178 025.26
24 A	4 poles		0178 026.27
24 A	5 poles		0178 027.20
24 A	10 poles		0178 032.25
24 A	20 poles		0178 033.26

Max. recommended torque : **0.6 Nm**